



## Installing Your Phone Adapter

All you have to do is insert the phone adapter between the POE (power injector) and your PC or router:

1. Plug the network cable out of your router or PC
2. Plug this cable into the WAN port on the phone adapter
3. Plug the spare network cable from the LAN port on the phone adapter to your router or PC
4. Plug in the power supply for the phone adapter
5. Plug your phone into the phone adapter ("PHONE1" socket)

The POE adapter will look like one of the following or similar.



This diagram shows the finished layout:

